



VideoIR Quick Start

- 1 - Inspect the shipment for damage and confirm all items are correct.**
- 2 - Use anti-static measures to mount the VideoIR camera in a test fixture.**
- 3 - Connect the RS-170 cable to a monitor, using provided BNC or RCA end to the camera, and plug the AC adapter in to a power outlet.**
- 4 - The camera should respond with a splash screen and a video image. Add a lens and focus the system.**
- 5 - Power down the camera and read additional instructions.**
 - a. Software instructions and install the software.**
 - b. Frame Grabber instructions and install the Frame Grabber.**
- 6 - Install any patches or up dates and begin testing the system.**